










ASSEMBLY INSTRUCTIONS
MODEL: 61394



Before assembly, please remove all parts from the carton, verifying that you have the correct quantities, and read all the instructions.

	<p>CAUTION: Because of the edges of some parts before assembly may be sharp, please handle unassembled parts carefully.</p>					
	<table border="1"><thead><tr><th>partlist</th><th>Qty</th></tr></thead><tbody><tr><td>A </td><td>1PC</td></tr><tr><td>B </td><td>4PC</td></tr></tbody></table>	partlist	Qty	A 	1PC	B 
partlist	Qty					
A 	1PC					
B 	4PC					

<p>1.</p> 	<p>2.</p> 
---	--

▲ ATTENTION ▲

Do not tighten any screws or bolts until the unit is completely assembled.
Ensure all bolts and screws are tightened before using. check bolts and screws every 6 months.
If any parts are missing, broken, damaged or worn, stop use of product until repairs have been made using factory authorized parts.
Failure to follow these warnings may result in Injury.